



## 829-12 Window Metlock Fitting Instructions

### Installing a Window Metlock

To fit a Window Metlock you will require the following tools:

- 8mm Spanner
- Hacksaw
- File

- Remove bolt and washer from lock body, unscrew locking pin to allow lock body to be fitted to handle, but do not remove.
- Slide lock body between window handle forks and ensure that taper on lock body coincides with taper on window handle. File base of lock body if necessary to ensure a tight fit. Re-insert bolt and washer in base of lock body and tighten with spanner.
- To lock handle, use key to tighten locking pin against window frame. If pin is too long use the hacksaw to cut off the required amount to ensure threaded section of locking pin is flush with the lock body.

### Additional Information

**Operation** - Using key, turn anti-clockwise to release Metlock.

**Security Tips** - Remember to fit ERA Metal Window Lock Ref: 901 or ERA Transom Lock Ref: 825 to top hinged windows.

**Maintenance** - Use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish.

